


REPLACEMENT PART INSTRUCTIONS FOR 59762, 59766, 59798, 59762KB, 59766KB, 59798KB




Use these instructions for help with replacing parts on the GP PRO enMotion® Flex Automated Towel Dispenser(s).

Use estas instrucciones para reemplazar piezas del dispensador automático por aproximación del rollo de toallas de papel GP PRO enMotion® Flex.

Utilisez ces instructions pour le remplacement d'éléments sur le distributeur de papier essuie-mains automatique sans contact GP PRO enMotion® Flex.


Cover | Cubierta | Couverture







Remove hinge rod that connects housings.


Retire la varilla que conecta las partes de la carcasa.

Retirez la tige de la charnière qui connecte les boîtiers.




Chassis | Chasis | Châssis





Push button key insert | Inserto de llave de pulsador | Clé d'insertion à bouton-poussoir



Roll Divider | divisor de rollos | séparateur de rouleaux

